

MANUAL FOR THE INSTALLATION OF STRUKER SHOWER TRAYS.

1. BEFORE THE INSTALLATION

- Please ensure before installation that there is nothing unusual or any defects on the surface of the shower tray. In which case, please do not install and contact your dealer.
- Please check that the water drains off correctly.
- Please keep the shower tray, until its installation, on a flat surface and in a horizontal position.
- The shower tray must be installed on a flat and even surface, independently to either being embedded within the floor surface, or installed onto the floor or a platform.

2. PREPARATION OF THE SHOWER TRAY

- Sandpaper the bottom surface so that it is slightly roughened this facilitates the fixing of the shower tray.

3. PREPARATION OF THE AREA WHERE THE TRAY IS TO BE FIXED.

- The mixture used should consist of mortar, in no case only sand, and must be perfectly levelled and dry. If this is not the case, the shower base can curve.
- Please do not forget to leave sufficient space for the waste hole and the pipes which connect the waste to the main pipes of the house. It is important that there is a gradient between the waste of the shower tray and the drains of the house, in order that the waste water can drain perfectly.

4. INSTALLATION OF THE SIPHON

- Please put the siphon in the correct place and connect it with the waste pipe. Ensure that there are no leakages and that the siphon covers completely the waste hole of the shower tray.

5. INSTALLATION OF THE SHOWER TRAY

- Fix around the whole perimeter of the shower tray a water impermeable tape, taking special attention to the corners, in order to avoid leakages between the shower tray and the wall.
- In order to ensure a safe fitting of the shower base, apply to the mortar base some lines of a polyurethane adhesive (Sicaflex, Ceys, etc.).
- Unwrap the shower tray and leave the protective- wrapping on the surface during the whole process of installation.
- Put the shower tray in the designated area, measuring up the waste hole in the shower tray to the previously installed waste pipe.
- Adjust the shower tray and make sure that it is levelled and the water can drain correctly. Please do not embed the shower tray more than 10 mm within the wall surface, in order to avoid later problems during the installation of the shower cubicle.
- After removing the protection, seal the circumference of the shower tray with neutral silicone. Please do not use in any circumstances acetic silicone. Remove spare silicone.
- Insert the cover for the waste hole.

IT IS VERY IMPORTANT THAT THE SHOWER TRAY IS WELL LEVELLED AND FIXED, IN ORDER TO ENSURE A FAILURE-FREE OPERATION AND A PERFECT FITTING OF THE SHOWER CUBICLE.

- Please leave the silicone to dry for 24 hours before using the shower tray for the first time. After this time you can check the correct functioning of the shower tray, and then the other elements (such as tiles and shower cubicle) can finally be installed.